



Step 1
Choose Template



Step 3
Make Schedule

EzPoster 解説



Step 2
Edit Content



Step 4
Export Content

工人舎デザイン株式会社

たった『4ステップ』で本格コンテンツが完成！！

カンタンコンテンツ作成ソフト
“ EzPoster ” イージーポスター同梱！



1



2



3



4

サイネージの設置
向きより縦長・横長
選択

テンプレート選択

カスタムテンプレート
を追加



既製/カスタムテンプレートを選択

編集作業

The screenshot shows the EzPoster software interface with the following components:

- Navigation Bar:** 01 Template > 02 Edit > 03 Schedule > 04 Output
- Message:** For each area for editing!
- Main Editing Area:** A menu titled "俺蔵 Lunch" with items like "11:30~15:00 ラストオーダー 14:", "＜サラダ・ドリンク＞ ¥1,888", "・ポーロース グリル 粒マスタードソース", "・オムハヤシライス", "・かまといづれんモウの クリームスープパスタ", "Beer・Wine + ¥ 400", and "Dessert + ¥ 200".
- Picture Edit Panel:** Shows "Picture Edit 00:00:10" with a video upload area containing "7135a346e245acc" and "00:00:06", and a "パスタ各種.jpg" image with "00:00:06".
- Bottom Bar:** Save, Open, Auto, Preview, Previous, Next.

Callout boxes and arrows indicate the following actions:

- 静止画追加 (Add Still Image):** Points to the menu items.
- テキスト追加 (Add Text):** Points to the menu text.
- 動画追加 (Add Video):** Points to the video upload area.

コンテンツを
順次
ループ再生

スケジュール(ループ再生)

Digital Signage EzPoster

01 Template > 02 Edit > 03 Schedule > 04 Output

According to the different play types add program!

Loop Play Timing Play

我郷 Lunch
00:01:00

俺威 Lunch
00:01:00

Save Open Previous Next

スケジュール(時刻設定)

時刻を指定して
コンテンツを
再生

The screenshot displays the EzPoster software interface, specifically the '03 Schedule' step. The window title is 'EzPoster' and the breadcrumb navigation shows '01 Template > 02 Edit > 03 Schedule > 04 Output'. A blue callout box on the left points to the 'Timing Play' radio button, which is selected. Below the radio buttons is a timeline with markers at 11:00, 15:00, 18:00, and 23:00. A blue bar highlights the period from 11:00 to 15:00. Underneath the timeline, there are three content slots. The first slot, corresponding to the 11:00-15:00 period, contains a menu titled '晚餐 Lunch' with a duration of 00:01:00. The second slot is empty with a plus sign and a duration of 00:00:00. The third slot, corresponding to the 18:00-23:00 period, also contains a '晚餐 Lunch' menu with a duration of 00:01:00. The bottom of the interface features buttons for 'Save', 'Open', 'Previous', and 'Next'.

配信(USBメモリ)

接続したUSBメモリ
を指定して
書き出し

The screenshot shows the EzPoster software interface. The top navigation bar includes '01 Template', '02 Edit', '03 Schedule', and '04 Output'. The main area is divided into two panels. The left panel, titled 'Playlist(Timing Play)', shows a vertical timeline with markers at 11:00, 15:00, 18:00, and 23:00, each with a corresponding poster thumbnail. The right panel has two tabs: 'To USB' (selected) and 'To Player'. Under 'To USB', there are two options: 'Removable Disks (E:)' and 'Removable Disks (D:)', both with checkboxes. A blue arrow points to the 'Removable Disks (E:)' option. Below these options is a checkbox for 'All Removeable Disks' and a 'Save To USB' button with a USB icon. At the bottom of the interface are 'Previous' and 'Return' buttons.

配信(ネットワーク)

設定しておいた
サイネージに
直接配信

The screenshot shows the EzPoster software interface. The top navigation bar includes '01 Template', '02 Edit', '03 Schedule', and '04 Output'. The main area is divided into two sections: 'Playlist(Timing Play)' on the left and 'To Player' on the right. The 'To Player' section contains a table with the following data:

<input type="checkbox"/>	Name	IP	Resolution
<input checked="" type="checkbox"/>	6EB01411	192.168.11.16	1080*1920

At the bottom of the 'To Player' section, there is a button labeled 'Publish To Player'. The bottom navigation bar includes 'Previous' and 'Return' buttons.